



Firmware Burning Procedure VP-732

Rev A

Master Firmware Burning Procedure VP-732/734

The information contained herein is the property of Kramer Electronics Ltd. and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorized by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.




Burning the MCU

This instruction describes how to burn any software for the first batch of VP-732/734.

Download the VP-732/734 AP

1. Open the latest version of the SW Download Tool.
2. Change the IP address to the actual IP address of the device (default 192.168.1.39).
3. Click **Disconnected** button.
4. Click **Load** button and choose the appropriate xx.pkg file.
5. Click **Upgrade FW** button.
6. Verify the burning ends successfully.



7. After the burning process is complete, power off the device and power it on again.