



Caution

When connecting the speakers, we recommend that you first connect the inputs and then connect the power:

1. Connect the inputs:
On the **SPK-OCA504**: the 5-pin terminal block and/or the 3.5mm mini jack and/or the L and R RCA connectors
On the **SPK-OCA508**: the 3-pin terminal block and/or the 3.5mm Mini Jack connectors.
2. Connect the power cord.
3. Switch the power on to AUTO or ON.

When disconnecting the speakers, always disconnect the power before disconnecting the inputs:

1. Switch the power off.
2. Disconnect the power cord.
3. Disconnect the inputs:
On the **SPK-OCA504**: the 5-pin terminal block and/or the 3.5mm mini jack and/or the L and R RCA connectors.
On the **SPK-OCA508**: the 3-pin terminal block and/or the 3.5mm Mini Jack connectors.