



RC-3TB Remote Control Panel

Congratulations on purchasing your Kramer **RC-3TB Remote Control Panel**.

The **RC-3TB** is used to remotely replicate buttons of a Master Controller, such as the **SL-14RC**.

See the **SL-14RC Master Controller User Manual** for details regarding the following:

- Defining the **RC-3TB Remote Control Panel**
- Rotary switch description
- Termination
- Connecting multiple **RC-3TB Remote Control Panels**

Button Labels

The backlit button caps are transparent and can contain the printed labels supplied.

Installing the Button Caps and Button Labels

To install a button cap and button label:

1. Using a screwdriver, remove the two screws holding the faceplate on and remove the faceplate. Place the faceplate and the screws aside.
2. Extract the required button labels from the sheet of labels supplied (see [Figure 2](#)).
3. Insert the labels into the supplied button caps bearing in mind the button cap orientation (see [Figure 1](#)). Note that the button caps must be mounted with the cap wings across the width of the faceplate, not along its length.
4. Place the button caps containing the new labels onto the button bases taking care to ensure correct orientation of the button cap wings.
5. Reinstall the faceplate and screw the two faceplate attachment screws in place.




Figure 1: Faceplate Showing Button Cap Wing Orientation

Figure 2 illustrates a sample button label sheet.




Figure 2: Sample Button Label Sheet

For the latest information on our products and a list of Kramer distributors, visit our Web site: www.kramerelectronics.com



Kramer Electronics, Ltd.

Web site: www.kramerelectronics.com

E-mail: info@kramereel.com

P/N: 2900-000596 REV 2
