



KRAMER ELECTRONICS LTD.

MV-5 Firmware Upgrade



MV-5 Firmware Upgrade Procedure

1. Turn on the MV-5.
2. Connect the computer to the MV-5 via Ethernet or RS-232.
3. Run K-Upload software.
4. Connect the K-Upload software to the MV-5 according to the K-Upload guide.

If connecting via Ethernet set K-Upload to UDP.

Default IP address 192.168.1.39.

Default UDP port 50000.

5. Select and upload appropriate KFW file.
6. Select and upload appropriate RBF file.
7. Perform factory reset as described in the User Manual of MV-5:
 - *Turn the device off.*
 - *Press and hold the Reset button on the rear panel of the device.*
 - *While holding the button depressed, turn the device on.*
 - *Hold the button depressed until the Window/Input is displayed.*
 - *Release the button.*