



WP-577VH Upgrade Procedure

1. Set the **WP-577VH** to the K-Link mode as shown in the **WP-577VH** user manual.
2. Connect your PC to the device via the RS-232 port as shown in the **WP-577VH** user manual.
3. Use K-Upload software (http://www.kramerelectronics.com/downloads/setups/k-upload_ver_1.0.0.65.zip) and follow the instructions in the K-Upload guide (<http://www.kramerelectronics.com/downloads/manuals/k-upload.pdf>) to upgrade the device.